

HELLO!

You're almost there just a few easy steps and your SPLASHBACK artwork will be securely installed.

Our artwork is supplied with a floating frame mount and a cleat hardware system for a secure, level and flush hanging result. The system works by interlocking the two aluminum rails. Once you've installed the wall bracket, the rail on the back of the frame will slide down into place for a perfect fit!

HOW TO HANG

Determine where you'd like to position your artwork by holding it in place on your wall. Use a pencil to mark the wall along the top edge of your artwork. Find the centre point of that line and mark it with a +. *We recommend a min. 2" space at top to allow for easy access when hanging.*

Measure 4" down from that point and draw a 4-6" horizontal line using the level.

Remove the bottom rail from the back of the frame and attach this rail on the wall with the bottom ledge aligned with the horizontal line and centred on the +.

There are two installation options:

A. *(recommended)* Using appropriate screws (drywall, wood, tile) secure the rail using two screws (you can drill through the tape without peeling the backing)

B. For a no-drill installation, peel the protective tape off the back of the cleat and stick on the wall using the line you drew. Press down on the length of the rail and leave 24 hours before hanging your artwork.

To hang, place your artwork flush against the wall, slightly above the wall bracket and slide it down to interlock the two cleats .

Enjoy!

TOOLS

tape measure
pencil for marking wall
level
2x screws
screwdriver or drill
approx 30 minutes